



FR FACE MASK

Added Layer of Protection

TIE BACK

Custom Fit



C6 FM-2-TB



NB FM-2-TB

ELASTIC LOOP

Close Fit



C6 FM-2



NB FM-2

ADJUSTABLE

Best of Both Worlds Fit



C6 FM-2-ADJ



NB FM-2-ADJ

X-BACK

Best Option for Comfort



FRONT

C6 FM-2-XBK



BACK

NB FM-2-XBK

ELASTIC BACK

Convenience

C6 FM-2-EB



DISCLAIMER: We make NO medical claims with regard to the usage of these masks





FR FACE MASK

MATERIAL

- Fire retardant fabric (NB = Nomex Blend / C6 = INT C6 BLK PW)
- ARC Rated fabric (HRC / CAT 2)
Nomex Blend (NB)= 12 ATPV
C6= 20 ATPV
- Washable (FR protection will not wash or wear out)

CONSTRUCTION

- Double ply construction
- Moisture-wicking
- Breathable
- Lightweight
- ONE SIZE fits most
- Stretchable
- Comfortable
- Soft
- Reusable

HOW TO WEAR

- Wear over N95 mask to extend usage of N95 mask
- Wear alone for ADDED layer of protection
- Easy to wear and take off

DESIGNED TO

- Discourage touching of nose and mouth
- Decrease the spread of wearer's airborne particles from coughing or sneezing
- Reduce droplets and particles inhaled by the wearer

CARE AND USE

- Wash/sanitize your hands before donning.
- Place CLEAN mask over nose and mouth.
- The top of the mask should rest on the bridge of your nose.
- The bottom of the mask should cover your chin, resting underneath your chin
- When removing, tilt your head forward.
- Let the mask fall forward, away from your face.
- Sanitize your hands immediately after removing the mask.

HOW TO WASH AND DRY

- FR Face Masks are reusable.
- Wash your mask before first use.
- It is important to wash between each wear.
- Wash ALONE using standard home laundry or hand wash.
- Regular detergent (no bleach, no fabric softeners, no alcohol, no chemical sanitizers).
- Warm or Cold water (not to exceed 105°F).
- Line dry in cool shaded location.
- Dry thoroughly – do NOT wear a wet FR Face Mask!

DISCLAIMER: We make NO medical claims with regard to the usage of these masks

